



INSTRUCTIONS ON HOW TO INSTALL ONE PIECE SLING

The same instructions apply for a 2 piece sling. Please call us with any questions at 954-970-7497.



Tools needed to complete this task: See Pic.1

- ✓ Flat head screw driver
- ✓ Utility knife or scissors
- ✓ Pliers
- ✓ Rubber mallet (optional)
- ✓ Impact drill
- ✓ Clamp / Spreader tool
- ✓ Wrench (if no drill)

Step one: Remove end caps

If you will use the same end caps, be careful removing them, they can be very dry and brittle and break easily. Use a flat head screw driver and remove the end caps. As shown in Pic.2 and 3.





Step two: Cut old slings

Using a utility knife or scissors, cut the old sling down in the middle. If your chair has a bar in the back, at this point it will come out.

Slide the two old sling pieces out of the rails one at a time and if necessary use pliers to pull them out.

As shown in Pic.4,5,6 and 7.



Step three: Insert splines



Slide the plastic splines into the sling pockets on both sides as shown in (Pic.8)




How to install slings

Step four: Insert sling on one side

Make sure to keep the sling tag at the top of the chair (differentiates the top from the bottom dimension of the sling).

Insert and slide the sling fabric in one of the rails; pull the sling down until the end of the rail. As shown in Pic.9,10 and 11.



Step five: Remove bolts



Use an impact drill to remove all the bolts (spacers or washers) that hold the rail of the side you inserted the sling as shown in (Pic.12)



Step six: Insert the other side of the sling



Insert and slide the sling fabric in the rail that is still attached to the frame; pull the sling down until the end of the rail as shown in (Pic.13)

Step seven: Loosen bolts



On the side that is still attached to the frame, loosen all bolts $\frac{3}{4}$ " of the way using an impact drill as shown in (Pic.14)

Step eight: Attach loose rail



Line up the holes of the loose rail with the holes of the frame; insert the bolts (spacers or washers) and tighten them using your fingers for now as shown in (Pic.15)



How to install slings

Step nine: Align sling



Pull the sling until it is even with both ends of the rails, and if necessary, use pliers to eliminate wrinkles on the fabric.

Note: Do not apply pressure on the pliers, it may cut the sling as shown in (Pic.16)

Step ten: Spread rails



A spreader tool is needed and you can find it on our website under tools.

Turn the chair upside down and put the spreader tool in the rails behind the chair; doing so will help to stretch the fabric.

Note: The fabric was made to stretch up to 1 3/8". See (Pic.17)

Step eleven: Tighten bolts



Use an impact drill to tighten all bolts as shown in (Pic.18 and 19)



Step twelve: Cut the spline



Cut all the excess spline as shown in (Pic.20)

Step thirteen: Insert end cap



Using a rubber mallet, gently tap the end caps into the sling rails as shown in (Pic.21)

Very Important: Please read, OutdoorPatioSupplies.com is not responsible for any damage caused to your sling frames or to sling fabric. Those using the information in this guide do so at their own discretion.




HOW TO INSTALL A BAR IN THE BACK OF THE CHAIR

If your chair has a bar in the back, please follow the instructions below:

Bar type: Curved with flat ends or straight bar

Turn the chair upside down and put the spreader tool on the top part of the rails. Spread the rails until the holes of the bar and the holes of the rails are aligned. Insert the bolts and using an impact drill tighten them up. As shown in Pic.1,2 and 3.



Bar type: Curved bar

Turn the chair upside down and put the spreader tool on the top part of the rails. Insert one end of the bar into one of the holes of the rail. Spread the rails until you can insert the other end of the bar into the other hole of the rail. As shown in Pic.4,5 and 6.





Bar type: Straight slide in the bar

Turn the chair upside down and put the spreader tool on the top part of the rails.

Remove the end cap.

Insert one end of the bar into the rail (that has the hole) and remove the end cap of the opposite side. Spread the rails and slide the bar in it. Put the end cap back. As shown in Pic.7 and 8.



Very Important: Please read, OutdoorPatioSupplies.com is not responsible for any damage caused to your sling frames or to sling fabric. Those using the information in this guide do so at their own discretion.